

- The **"Replacement"** access code: only valid for one SCM computer. This access code is for replacing the SCM computer; it allows adjustment of the system's time and input of the crane's serial number.
To obtain this access code, contact your usual **Potain** service network agent.

**Note**

Under no circumstances may this code be sent to a third party. The use of this code is reserved exclusively for the cases listed and described in the technical manual to the exclusion of any other use. Since using this code gives access to the machine's settings, incorrect parameterization can cause a risky situation that could lead to an accident. **Manitowoc** accepts no responsibility in the event of mis-use of this code, in the event of use not in accordance with the technical manual, or in the event of use in cases other than those described in the technical manual of the crane.

**Note**

Three situations enable the access code to be deactivated:

- Manual stop of the radio control.
- Automatic stop of the radio control via the **"Auto-OFF"** function.
- Pressing the emergency stop button.

Access code rights CCS

	Fitter	Technician	Temporary	Replacement
Adjustments/Settings	YES	Yes	YES	NO
Anti-collision system adjustment	YES	YES	YES	NO
Top Site adjustment	YES	YES	YES	NO
Commissioning mode	YES	YES	YES	NO
Fitting mode	YES	YES	YES	NO
Shunt mode	NO	NO	YES	NO
Serial no. adjustment	NO	NO	NO	YES
System time setting	NO	NO	NO	YES
Free standing height adjustment ⁽¹⁾ ⁽¹⁾ depending on model	NO	NO	YES	NO
Updating software using "CCS Flash"	NO	YES	YES	NO
High maintenance position and low maintenance position ⁽¹⁾ ⁽¹⁾ depending on model	NO	YES	YES	NO

ENU / 2023-05-10