



3. 4. PRESET SPEEDS

		LI1	LI2	LI3	LI4	LI5		
	Notch 1	1	0	0	0	0	10 Hz	LSP
	Notch 2	1	0	1	0	0	45 Hz	SP2
	Notch 3 <1800 Kg	1	0	1	1	0	73 Hz	SP4
	Notch 3 <1400 Kg	1	0	1	0	1	90 Hz	SP6
	Notch 3 < 700 Kkg	1	0	1	1	1	120 Hz	HSP
	Notch 1	0	1	0	0	0	10 Hz	LSP
	Notch 2	0	1	1	0	0	45 Hz	SP2
	Notch 3 <1800 Kg	0	1	1	1	0	73 Hz	SP4
	Notch 3 <1400 Kg	0	1	1	0	1	90 Hz	SP6
	Notch 3 < 700 Kg	0	1	1	1	1	120 Hz	HSP
LI6 : RUN								